DINAX® EDGE CLEANER F

surface cleaner for the removal of grease-line

APPLICATION:

Gel-like liquid to remove the so-called grease-line from swimming-pools

By using the product, you can remove the grease-line that precipitates on vertical swimming-pool walls above the water line. The product can be used even when there is water in the pool.

USE:

Pour some **DINAX® SZEGÉLYTITSZTÍTÓ F** on a sponge and apply it onto the surface to be cleaned.

After a few minutes, rinse the surface and clean it with a sponge. In case the dirt is more aggressive, maybe you will need to repeat the process. Due to its gel-like consistence, it is especially suitable for treating vertical surfaces.

If you can, please do not rinse the product directly into the water, but use a wet cloth to remove it from the surface . If the product gets into the water, it results in the rise of the pH value. After using the product check water pH and adjust if necessary.



When using the product, use appropriate safety gloves and goggles to handle this alkaline chemical. Do not use it on surfaces that dissolve in alkali (e.g. aluminium). No bathers are allowed to use the swimming-pool while the product is in use.

AVAILABLE SIZES:

1 kg bottle, 5 kg drum, 10 and 20 kg reusable container.

Registration number: BP/FNEF-TKI/09013-2/2018

